

# AEROSANA VISCONN

## TIPS, SETTINGS, EQUIPMENT AND ACCESSORIES

**AEROSANA VISCONN** can be applied by painting or spraying. For large surfaces, spraying it on using an airless sprayer is recommended.



### Application with an airless sprayer

Coverage approx. 400 - 850 g/m<sup>2</sup>

Pressure setting: 90 -150 bar

Filters: We recommend that you work without filters. Remove the filter from the spray gun and also the main filter from the pumping equipment. The strainer on the suction tube is sufficient in order to retain large particles or coarse dirt.

### Application with a paintbrush

Coverage approx. 600 - 900 g/m<sup>2</sup>

### Airless sprayers

	Best price	Price
Graco GX21	Best price	approx. € 1,000*
Graco Classic 390-395 PC (Hi Boy)	Starter	approx. € 3.000*
Graco Classic 495-595 PC (Hi Boy)	Profi	approx. € 3.800*
Graco XFORCE HD	Rechargeable device	approx. € 1.800*

### Accessories

	Price
Airless nozzles: 317 / 319 / 321 / 519	approx. € 30 - 50/nozzle*
Extension pole: 25 - 50 cm extension (Adapter recommended)	approx. € 35 - 60/extension pole*

\* The prices stated here are guideline values (gross). Please ask your dealer about actual sales prices.

### Cleaning

If AEROSANA VISCONN has not yet set, cleaning with water is sufficient. Cross-linked and dried material can be cleaned with pro clima GLUMEX and/or petrol, paraffin, universal thinner or acetone. Ethanol is not suitable for use for cleaning.

### Note



Airless nozzle numbers, taking the examples of 319 and 519:

- The first digit stands for the spray angle of 3° or 5° here.
- The second and third digits stand for the throughput or size of the nozzles (Ø in inches), here 0.19 inches.



[www.proclima.com](http://www.proclima.com)

... and the insulation  
is perfect

